


**BEN0006**

# Harper Teak Backless Bench 220






**(FR)** Notice de Montage -  
Utilisation - Entretien

**(IT)** Istruzioni per il Montaggio,  
l'Uso e la Manutenzione

**(DE)** Montage - Verwendung -  
Wartungshandbuch

**(ES)** Instrucciones de Montaje,  
Utilización y Mantenimiento


**(EN)** Assembly - Use -  
Maintenance Manual






JCBC Bolt






L Key




Flat Ring Washer




**NOT INCLUDED**  
**NON FOURNIS**



iii




180°



**DIN0031**

# Harper Teak Table 220






**(FR)** Notice de Montage -  
Utilisation - Entretien

**(IT)** Istruzioni per il Montaggio,  
l'Uso e la Manutenzione

**(DE)** Montage - Verwendung -  
Wartungshandbuch

**(ES)** Instrucciones de Montaje,  
Utilización y Mantenimiento

**(EN)** Assembly - Use -  
Maintenance Manual






JCBC Bolt






L Key



Flat Ring Washer



**NOT INCLUDED**  
**NON FOURNIS**



iii

