


TVS0003\_3 | Jonàk OAK TV Unit 140  
TVS0010\_3 | Jonàk WALNUT TV stand 140

---





FR Notice de Montage -  
Utilisation - Entretien

IT Istruzioni per il Montaggio,  
l'Uso e la Manutenzione


DE Montage- Verwendung-  
Wartungshandbuch

ES Instrucciones de Montaje,  
Utilización y Mantenimiento


EN Assembly-Use-  
Maintenance Manual



1 X



1 X




1 X

M8 X35   **A X6(+1)**

M8  **B X6(+1)**

M8\*14\*2  **C X6(+1)**

M5  **D X1**





A X6



B X6





C X6





D X1

1




2





3



4

