


TVS0077

TV Stand Plywood Black & Rattan 144










FR Notice de Montage -
Utilisation - Entretien

IT Istruzioni per il Montaggio,
l'Uso e la Manutenzione

DE Montage - Verwendung -
Wartungshandbuch

ES Instrucciones de Montaje,
Utilización y Mantenimiento

EN Assembly - Use -
Maintenance Manual







A x6




B x6

I



C x1


ii







ⓓ X12

iii



IV





V

