


TVS0009
TVS0080

Ellie Walnut TV Unit 180
Ellie Oak TV Unit 180





(FR) Notice de Montage -
Utilisation - Entretien

(IT) Istruzioni per il Montaggio,
l'Uso e la Manutenzione


(DE) Montage - Verwendung -
Wartungshandbuch


(ES) Instrucciones de Montaje,
Utilización y Mantenimiento

(EN) Assembly - Use -
Maintenance Manual





  (A) x 5 (+1)
M8x40




 (B) x 5 (+1)
M8x13



 (C) x 5 (+1)
M8x14



 (D) x 1
5#



(A) x 5




(B) x 5



(C) x 5



(D) x 1



CHARNIERES / HINGES / BISAGRA / CERNIERA / SCHARNIER

FR

EN

ES

IT

DE

